Warranty

D & R Electronics warrants its new products to be free from defects in material and workmanship, under normal use and service, for a period of one year on parts replacement, and one year on labor.

This warranty applies only to original purchasers acquiring the product directly from D&R Electronics, or its authorized dealers. Warranty will not be recognized without proof of purchase or bill of sale. This warranty is not transferable.

The warranty begins on the date of delivery to the first user/purchaser. This warranty shall not apply to products which must be repaired due to normal wear and tear, negligence, improper installation, abuse, misuse, or which have been altered or modified at a facility other than D & R Electronics, or its authorized depot center. Units proved to be defective within the warranty period, based on an examination by D&R Electronics, will be replaced or repaired at D & R Electronics' option. This warranty does not cover travel expenses or labor charges for removal or installation.

Lamps, flash tubes, batteries or other items considered consumables are not covered under warranty.

This warranty is in lieu of all other express warranties. D&R Electronics makes no other warranties, expressed or implied, than the express warranties contained herein.

PRODUCT RETURN POLICY

In order to provide you with faster service, product returns for repair or replacement, must have a **Return Goods Authorization Number (RGA number)**. Please contact our company to obtain a RGA number before you return the product to D & R ELECTRONICS. Write the RGA number clearly on the package. Be sure you use sufficient packing materials to avoid damage to the product being returned while in transit. D & R ELECTRONICS assumes no responsibility or liability for expenses incurred for the removal and/or the installation of products requiring service and/or repair. Repairing or replacing product is at the discretion of D & R ELECTRONICS.

D&R ELECTRONICS Co. LTD.

8820 George Bolton Pkwy.

Bolton, Ontario L7E 2Y4,


USA 2321 Kenmore Ave. Buffalo, NY 14207


Tel.: (905)951-9997 Fax: (905)951-0019 Toll Free 1-800-538-7338 www.dandrelectronics.com USA



WINDOW BARS 937-0317A

Installation Instructions Ford Interceptor Utility 2011+





Parte Liet

I dito Elot		
Part #	Description	Qty
837-0365A(DS)	Drivers side window bar	1
837-0366A(PS)	Passengers side window bar	1
401-0013	Screw - #8-18 x 3/4 Tek, Hex, Zinc	16

Installation Instructions

Step 1.

Starting with the driver side rear door, remove the triangular panal lo-






Step 2

Place PS Window Bar into position in the

drivers side rear side window with the bars facing the glass. The window bar should sit flush with the curvature of the door and that there is a gap between the bottom of the window bar frame and the top of the door panel. The door frame

should be seen through all the screw holes.





Step 3 **Rivet Option**

Mark, Drill holes and rivet Guard to Doo Frame

Self Tapping Screws Option (If Rivet Gun unavailable)

Drill the provided #8x#14" Tek Screws through the holes in the window bar frame into the door frame. Do this for all 8 holes in each window bar.



Step 4 Repeat steps 1—3 for the rear side window in the Driver side door.

