


# 2020 Utility Window Bars

(937-0360A) Installation Manual



Content	Page
Hardware and Component List	2
Installation Instructions	3-4
Warranty and Return Policy	5

Hardware List		
Part Number	Description	Qty
411-0067	10-24 x 1/2" Carriage Bolt	8
403-0007A	#10 Flat Washer	14
402-0011	10-24 Nyloc Nut	8
411-0132	10-32 x 3/4" Hex Self Tap Screw	6
401-0180*	6-32 x 3/4" PAN Head Bolt	8
402-0026*	6-32 Nyloc Nut	8

# Component List


ltem Num- ber	Part Number	Description	Qty
А	837-0493A	Window Bar DS	1
В	837-0494A	Window Bar PS	1
С	837-0497A	Top Thin Side Clamp	2
D	837-0495A	Bottom Thin Side Clamp	2
E	837-0499A*	Genesis Wire Cover Brkt	2
F	837-0498A*	Genesis Wire Tunnel Brkt	2

\* - Only for optional Light Kit

### Installation Instructions:


## Step 1:

Loosely attach the provided brackets in the correct locations as shown using  $10-32 \times 1/2^{\prime\prime}$  Carriage Bolt (x4), #10 flat washer (x4) and #10 Nyloc Nut (x4). The bracket with the two holes on the flange is mounted near the top of the Window Guard and the bracket with no holes in mounted near the bottom.




### Step 2 (For optional light kit):

For the MR6 or Genesis (sold separately) install the Genesis Wire Cover Bracket (837-0499A), Genesis Wire Tunnel Bracket (837-0498A) and the Surface Mount Housing using 6-32 x 3/4" PAN Head Bolt (x4) and 6-32 Nyloc Nut (x4).



# Step 3:


Lower both of the both rear windows. Starting with the driver side rear door place the Window Bar on the door and align the edges to ensure that it does not pass the edge of the plastic frame. The bottom bracket previously installed will slide into the window channel.





### Step 4:

Adjust the brackets until aligned. Secure the Window Bar to the Door using the 10 -32 x 3/4" Self Tapping Screws (x3) and #10 flat washer (x3)provided and tighten down brackets.



#### WARRANTY

D & R Electronics warrants its new products to be free from defects in material and workmanship, under normal use and service, for a period of one year on parts replacement, and one year on labor.

This warranty applies only to original purchasers acquiring the product directly from D&R Electronics, or its authorized dealers. Warranty will not be recognized without proof of purchase or bill of sale. This warranty is not transferable.

The warranty begins on the date of delivery to the first user/purchaser. This warranty shall not apply to products which must be repaired due to normal wear and tear, negligence, improper installation, abuse, misuse, or which have been

altered or modified at a facility other than D & R Electronics, or its authorized depot center. Units proved to be defective within the warranty period, based on an examination by D&R Electronics, will be replaced or repaired at D & R Electronics' option. This warranty does not cover travel expenses or labor charges for removal or installation. Lamps, flash tubes, batteries or other items considered consumables are not covered under warranty.

This warranty is in lieu of all other express warranties. D&R Electronics makes no other warran-

#### PRODUCT RETURN POLICY

In order to provide you with faster service, product returns for repair or replacement, must have a **Return Goods Authorization Number (RGA number)**. Please contact our company to obtain a RGA number before you return the product to D & R ELECTRONICS. Write the RGA number clearly on the package. Be sure you use sufficient packing materials to avoid damage to the product being returned while in transit.

D & R ELECTRONICS assumes no responsibility or liability for expenses incurred for the removal and/or the installation of products requiring service and/or repair. Repairing or replacing product is at the

#### D&R ELECTRONICS Co. LTD.

USA

2299 Kenmore Ave Building #3, Doors 11-14 Buffalo, NY, 14207

Toll Free 1-800-538-7338

1997 1019

www.dandrelectronics.com

CANADA

8820 George Bolton Pkwy. Bolton, Ontario L7E 2Y4

Tel.: (905)951-9997 Fax: (905)951-0019