

## WARRANTY

D & R Electronics warrants its new products to be free from defects in material and workmanship, under normal use and service, for a period of one year on parts replacement, and one year on labor. This warranty applies only to original purchasers acquiring the product directly from D&R Electronics, or its authorized dealers. Warranty will not be recognized without proof of purchase or bill of sale. This warranty is not transferable. The warranty begins on the date of delivery to the first user/purchaser. This warranty shall not apply to products which must be repaired due to normal wear and tear, negligence, improper installation, abuse, misuse, or which have been altered or modified at a facility other than D & R Electronics, or its authorized depot center. Units proved to be defective within the warranty period, based on an examination by D&R Electronics, will be replaced or repaired at D & R Electronics' option. This warranty does not cover travel expenses or labor charges for removal or installation. Lamps, flash tubes, batteries or other items considered consumables are not covered under warranty. This warranty is in lieu of all other express warranties. D&R Electronics makes no other warranties, expressed or implied, than the express warranties contained herein.

## PRODUCT RETURN POLICY

In order to provide you with faster service, product returns for repair or replacement, must have a **Return Goods Authorization Number (RGA number)**. Please contact our company to obtain a RGA number before you return the product to D & R ELECTRONICS. Write the RGA number clearly on the package. Be sure you use sufficient packing materials to avoid damage to the product being returned while in transit. D & R ELECTRONICS assumes no responsibility or liability for expenses incurred for the removal and/or the installation of products requiring service and/or repair. Repairing or replacing product is at the discretion of D & R ELECTRONICS.

**D&R ELECTRONICS Co. LTD.**

### CANADA

8820 George Bolton Pkwy.  
Bolton, Ontario L7E 2Y4

Tel.: (905)951-9997  
Fax: (905)951-0019

[www.dandrelectronics.com](http://www.dandrelectronics.com)

### USA


2321 Kenmore Ave.  
Buffalo, NY 14207

Toll Free 1-800-538-7338



## WINDOW GUARDS-937-0320A FORD TAURUS INTERCEPTOR SEDAN 2012

### Installation Instructions



### Parts List

Part #	Description	Qty
937-0320A	Taurus Interceptor Sedan 2012 WINDOW BAR (DS/PS)	1
837-0375A	FRONT TOP BRACKETS	2
837-0376A & B	FRONT MID BRACKETS	1 EACH
837-0377A & B	FRONT BOTTOM BRACKETS	1 EACH
937-0322A	LIGHT KIT (OPTIONAL)	
837-0381A	WIRE PLATE A	2
837-0382A	WIRE PLATE B	2


### Hardware List

Line #	Description	Qty
1	CARRIAGE BOLT 1/4-20 X 5/8"	6
2	WASHER 1/4"	6
3	NUT 1/4-20 NYLOCK	6
4	SCREW #6-32 X 3/4" (FOR OPTIONAL LIGHT KIT)	8
5	NUT #6-32 NYLOCK (FOR OPTIONAL LIGHT KIT)	8

# Installation Instructions (DS/PS)


## Step 1

Roll down the window place the window guard as shown.



## Step 2

Place front brackets and secure using hardware, Line 1,2 & 3. FASTEN, BUT DO NOT TIGHTEN.





## Step 3

Adjust the window bar and then tighten hardware from step 2.




## Step 5 (For Optional Light Kit)

Place the Lights (SOLD SEPERATELY), Wire plate A and Wire plate B. CAUTION- make sure no wire gets pressed between plates.



## Step 6 (For Optional Light Kit)

Secure lights and plates using hardware, line 4 & 5.



You have now completed installing the Window Guard.