WARRANTY

D & R Electronics warrants its new products to be free from defects in material and workmanship, under normal use and service, for a period of one year on parts replacement, and one year on labor. This warranty applies only to original purchasers acquiring the product directly from D&R Electronics, or its authorized dealers. Warranty will not be recognized without proof of purchase or bill of sale. This warranty is not transferable. The warranty begins on the date of delivery to the first user/purchaser. This warranty shall not apply to products which must be repaired due to normal wear and tear, negligence, improper installation, abuse, misuse, or which have been altered or modified at a facility other than D & R Electronics, or its authorized depot center. Units proved to be defective within the warranty period, based on an examination by D&R Electronics, will be replaced or repaired at D & R Electronics' option. This warranty does not cover travel expenses or labor charges for removal or installation. Lamps, flash tubes, batteries or other items considered consumables are not covered under warranty.

This warranty is in lieu of all other express warranties. D&R Electronics makes no other warranties, expressed or implied, than the express warranties contained herein.

PRODUCT RETURN POLICY

In order to provide you with faster service, product returns for repair or replacement, must have a **Return Goods Authorization Number (RGA number)**. Please contact our company to obtain a RGA number before you return the product to D & R ELECTRONICS. Write the RGA number clearly on the package. Be sure you use sufficient packing materials to avoid damage to the product being returned while in transit.

D & R ELECTRONICS assumes no responsibility or liability for expenses incurred for the removal and/or the installation of products requiring service and/or repair. Repairing or replacing product is at the discretion of D & R ELECTRONICS.

D&R ELECTRONICS Co. LTD.

CANADA USA

8820 George Bolton Pkwy. 4500 Witmer Industrial Estates Bolton, Ontario L7E 2Y4 Niagara Falls, NY, 14305-1386

Tel.: (905)951-9997 Toll Free 1-800-538-7338

www.dandrelectronics.com

Fax: (905)951-0019



Product ID: 935-0070A Caravan 09-2013
Description: Speaker Bracket For DRCS100 or Optional DRCS110
INSTALLATION MANUAL









DCRS 110 Mounted With 935-0066A Adapter Bracket



Parts List & Hardware List

Quantity	Part #	Description
1	835-0018A	Caravan Speaker Bracket Plate
1	835-0019A	Caravan Speaker Bracket
1	935-0066A (OPTIONAL)	DRCS110 Adapter Bracket (OPTIONAL FOR DRCS110 Speaker install ONLY)
4		BOLT, 1/4-20 x1", S.S CARAIGE BOLT
4		1/4-20 NYLOC NUT S.S
4		WASHER,1/4 LOCK 18.8 S.S.

Contents:

Parts List————————————————————————————————————	1
Installation Instructions————	2-
Warranty & Product Return Policy	

1/29/2013

Installation Instructions

Step 1

Remove front bumper

Step 2

Place speaker bracket front over crash bar Plastic and mark with tape 1/2in from bracket




Step 3
Remove plastic crash bar cover and cut middle section out. Then re-install





4 Clips hold the plastic to the crash bar.

Step 4 Place front bracket on crash bar and bolt back plate using 4x 1/4-20 Carriage bolts, with 4 washers and 4 Nyloc nuts.



Step 5

Install DRCS100 Speaker to bracket, complete wiring re install bumper. This completes the DRCS100 install into your 09-2013 Dodge Caravan. Skip this step and go to Step 6 if your using the DRCS110 Speaker.





Step 6 Installation for the DRCS110 Speaker

Install adapter bracket using 1/4-20 hardware supplied with bracket to speaker bracket as shown.



Step 7
Mount DRCS110 Speaker to adapter bracket with supplied 1/4-20x1-1/4in Hex bolts in speaker box.





Step 8
Wire speaker and re install front bumper. This completes the installation for the DRCS110 into your 09-2013 Dodge Caravan.